

# Wallpaper



## INSTALLATION INSTRUCTIONS

### Product: Matte (Nonwoven)

#### Before you cut and hang, please read these notes:

1. Ensure correct wallcovering and the correct amount of wallcovering to complete the installation.
2. Inspect the wallcovering carefully to ensure it is free of defects. If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until IBB Design is notified. NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL. All claims must be made within 30 days of the shipping date. No labor claims will be allowed at any time.

#### For best results, drywall surface should be prepared to at least level 4 prior to installation.

Rinse wall and allow to dry. All surfaces to receive wallcovering must be smooth, clean, dry and structurally sound. Any mold or mildew MUST be removed from walls and hanging surfaces prior to installation. Any mold or mildew MUST be removed from walls and hanging surfaces prior to installation. Walls should not contain in excess of 4% residual moisture content. A moisture meter should be used to determine moisture content. Moisture infiltration and accumulation can lead to mold or mildew growth and must be corrected PRIOR to the installation of the wallcovering. If you are unsure if moisture problems are present, consult a qualified professional before proceeding. This product is intended for use in buildings that are properly designed and maintained to avoid moisture infiltration, condensation and or accumulation at wall cavities and wall surfaces, particularly in warm, humid climates. Do not install wallcovering unless a temperature above 65°F is maintained in both areas of installation and storage for at least 48 hours prior to installation. We recommend that you prime all surfaces with a universal mold inhibiting wallcovering primer/sealer.

### Application

1. Recommend the use of a premium quality, strippable adhesive. Do not dilute the adhesive. Roman adhesives Eco Brand are recommended to comply with NSF-342 sustainability.
2. Apply the recommended adhesive to the wall using a paint roller. Cover a surface of 1-3 strips, depending on the degree of the wall absorption. Spread the paste evenly.
3. Hang the first strip parallel to a plumb line or laser. Ensuring extra space at ceiling and floor for any drift.
4. Hiding Seams: With a dark pattern, it is useful to use watercolors to dye seams. You can match the color of the wallpaper with watercolors and paint the edge of the wallcovering to hide the seam.
5. Avoid burnishing the face of the material. Use a plastic scraper with a fabric covered edge to smooth.
6. Do not rub. Do not allow the adhesive to dry on surface as it may leave a residue. Wah off excess paste from the wallcovering as you hang it with a soft sponge or rag.
7. Overlap the second strip over the first strip. Tape the seam underneath with a low adhesive tape to avoid getting paste on the wallcovering. We recommend using the seam buster from Advance to double cut.
8. After three strips are installed, inspect the wallcovering. If the pattern effect or mural is not acceptable or if there is a variation in color, discontinue hanging and contact the dealer or distributor immediately. The manufacturer will not be responsible for material beyond three strips. Defective material will be replaced. The manufacturer will not be responsible for any labor.

*The Shay Geyer Collection Available Exclusively at IBB Design Fine Furnishings*  
5798 GENESIS COURT, FRISCO, TX 75034 | 214.618.6600 | IBBDESIGN.COM

