

# Wallpaper



## INSTALLATION INSTRUCTIONS

### Product: Paper Weave

Before you cut and hang, please read these notes:

1. The correct wallcovering and the correct amount of wallcovering to finish the installation.
2. Inspect the wallcovering carefully to ensure it is free of defects: This is a natural product and will have color variations. If no defect is evident before installation, the material should be inspected after three (3) strips are installed. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until IBB Design is notified. **NO CLAIMS WILL BE ALLOWED FOR MORE THAN (3) STRIPS ON THE WALL.** All claims must be made within 30 days of the shipping date. No labor claims will be allowed at any time.

**Strongly recommend preparing wall to level 5.**

Rinse wall and allow to dry. All surfaces to receive wallcovering must be smooth, clean, dry and structurally sound. Newly plastered walls must not have excessive quantities of lime or alkali. Prime walls with heavy-duty acrylic/latex wallcovering primer. Plaster and masonry wall surfaces should not exceed 5.5% moisture as measured by a moisture meter. A moisture meter should be used to determine moisture content. Do not install wallcovering unless a temperature above 55 degrees is maintained in both areas of installation and storage for three (3) days after the installation. If there are any questions concerning the surface to be covered, a test installation of at least three strips applied three days in advance of the main installation is recommended.

### Application

1. This wallcovering requires the use of a heavy duty, premixed vinyl adhesive such as Roman 780, Roman 880, or Roman 888. Dilution of adhesive is not recommended.
2. Double Cutting - There is a 2cm (.78") overlap on the right side of the pattern for double cutting.
3. Apply the recommended adhesive to the back using a paint roller. Work the adhesive in to cover the back completely, and especially near the edges while taking care not to have any adhesive on the front side.  
Do not crease the wallcovering.
4. Hang the first strip parallel to a plumb line or laser.
5. After three strips are installed, inspect the wallcovering. If the pattern effect or mural is not acceptable or if there is a variation in color, discontinue hanging and contact the dealer or distributor immediately. The manufacturer will not be responsible for material beyond three strips. Defective material will be replaced. The manufacturer will not be responsible for any labor.
6. Hiding Seams: With a dark pattern, it is useful to use watercolors to dye seams. You can match the color of the wallpaper with watercolors and pain the edge of the wallcovering to hide the seam.

This product is intended for use in buildings designed and maintained to avoid moisture accumulation on or within wall, particularly in warm, humid climates.

*The Shay Geyer Collection Available Exclusively at IBB Design Fine Furnishings*  
5798 GENESIS COURT, FRISCO, TX 75034 | 214.618.6600 | IBBDESIGN.COM

   @IBBDESIGN    @IBBDesignFineFurnishings